

Appendix A. RTE-V853-IE Internal Commands

This document describes the internal commands of the RTE-V853-IE. These commands can be used as through commands in each debug monitor. Refer to the manual of the respective debug monitors for how to use the commands.

(Example) PARTNER/Win

>&	<<	Selects the through command mode.
>#ENV	<<	Internal command
>&	<<	Exits the through command mode.

Commands

Access break point setting	: ABP, ABP1, ABP2, ABP3, and ABP4 commands	A3
Access trace trigger setting #1	: ATP, ATP1, and ATP2 commands	A4
Access trace trigger setting #2	: ATP3 command.....	A5
Environment setting	: env command	A7
Help	: help command	A9
Initialization	: init command	A10
Memory mapping specification	: map command.....	A11
Cache area cancellation	: nc command	A12
Cache area specification	: ncd command	A13
Reset command	: reset command	A14
Real-time RAM monitor base	: rrm command.....	A15
Real-time RAM monitor read	: rrm command	A16
SFR	: sfr command.....	A17
Symbol file read	: symfile and sym commands	A18
Execution time display	: time command	A19
Execution trigger point setting	: TP, TP1, and TP2 commands	A20
Trace start and setting	: TRON command	A21
Trace termination	: TROFF command	A22
Trace result display	: TRACE command	A23
Version information display	: ver command	A25

Caution Do not use these commands when equivalent functions are supported by the debugger. If you issue a command when the debugger in use has an equivalent function, contention will occur between them, and either the command or the equivalent function is likely to malfunction.

Command syntax

The internal commands of the RTE-V853-IE are explained using the following notation.

Command name parameter

* A parameter enclosed in [and] is omissible. The horizontal line (|) separates optional parameters.

The command name is an alphabetic string. The command name string is separated from the first parameter by a space or tab character. A parameter is specified using an alphabetic character string or hexadecimal number. Parameters are separated by a space or tab character. (No operator can be used for hexadecimal numbers.)



ABP, ABP1, ABP2, ABP3, and ABP4 commands**[Format]**

```

abp [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
abp1 [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
abp2 [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
abp3 [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
abp4 [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]

```

[Parameters]

ADDR : An address value is specified in hexadecimal.

DATA : Data to be accessed is specified in hexadecimal.

MASK : A data mask is specified in hexadecimal.

read|write|access A type of status is specified.

read : Data read

write : Data write

access : Data access

byte|hword|word|nosize The size of data to be accessed is specified.

byte : Byte access

hword : Halfword access

word : Word access

nosize : No access size

/del : Any previous setting by the command is canceled.

[Function]

The ABP, ABP1, ABP2, ABP3, and ABP4 commands set or cancel an access break point. There are four access break points. The abp command specifies an unused break point automatically.

- The abp1, abp2, abp3, and abp4 commands are used to specify a break point explicitly.
- The data mask is used to specify invalid bits in the data.
- If a mask bit is 1, the corresponding data bit will not be compared. If the mask bits are ffffffff, for example, the accessed data will be utterly ignored.

[Example]

```
abp 1020 0 ffffffff access hword
```

A break occurs if a halfword at address 1020H is accessed (regardless of the bit configuration of the data).

```
abp 1020 100 0 write word
```

A break occurs if the word 100H is written to address 1020H.

```
abp2 /del
```

The abp2 command is canceled.

ATP, ATP1, and ATP2 commands**[Format]**

```
atp [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
atp1 [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
atp2 [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
```

[Parameters]

ADDR : An address value is specified in hexadecimal.

DATA : Data to be accessed is specified in hexadecimal.

MASK : A data mask is specified in hexadecimal.

read|write|access A type of status is specified.

read : Data read

write : Data write

access : Data access

byte|hword|word|nosize The size of data to be accessed is specified.

byte : Byte access

hword : Halfword access

word : Word access

nosize : No access size

/del : Any previous setting by the command is canceled.

[Function]

The ATP, ATP1, and ATP2 commands set or cancel an access trigger point. There are two access trigger points. The atp command specifies an unused trigger point automatically.

- The atp1 and atp2 commands are used to specify a trigger point explicitly.
- The data mask is used to specify invalid bits in the data.
- If a mask bit is 1, the corresponding data bit will not be compared.

Example) If the mask bits are ffffffff, the accessed data will be utterly ignored.

When any of these commands is issued, the trace buffer will be cleared, and tracing will newly begin.

[Example]

```
atp 1020 0 ffffffff access hword
```

Triggering occurs if a halfword at address 1020H is accessed (regardless of the bit configuration of the data).

```
atp 1020 100 0 write word
```

Triggering occurs if the word 100H is written to address 1020H.

```
atp2 /del
```

The atp2 command is canceled.

ATP3 command**[Format]**

```
atp3 [in|out] [ADDR [HADDR [DATA [MASK]]]] [read|write|access] [byte|hword|word|nosize] [/del]
atp3 [<|>|<>|<=|>=|eq] [ADDR [DATA [MASK]]] [read|write|access] [byte|hword|word|nosize] [/del]
atp3 noaddr [DATA [MASK]] [read|write|access] [byte|hword|word|nosize] [/del]
```

[Parameters]

in|out An address range is specified.

in : Addresses in a specified range are assumed to be valid.
 ADDR <= trigger address <= HADDR

out : Addresses out of a specified range are assumed to be valid.
 Trigger address < ADDR, HADDR < trigger address

ADDR : A lower address value is specified in hexadecimal.

HADDR : An upper address value is specified in hexadecimal.

<|>|<>|<=|>=|eq An address condition is specified.

< : Addresses lower than the specified address are made valid.
 Trigger address < ADDR

> : Addresses higher than the specified address are made valid.
 Trigger address > ADDR

<> : Any address not equal to the specified address is made valid.
 Trigger address <> ADDR

<= : Addresses lower than or equal to the specified address are made valid.
 Trigger address <= ADDR

>= : Addresses higher than or equal to the specified address are made valid.
 Trigger address >= ADDR

eq : Any address equal to the specified address is made valid.
 Trigger address = ADDR

noaddr Address conditions are ignored.

DATA : Data to be accessed is specified in hexadecimal.

MASK : A data mask is specified in hexadecimal.

read|write|access A type of status is specified.

 read : Data read

 write : Data write

 access : Data access

byte|hword|word|nosize The size of data to be accessed is specified.

byte : Byte access

hword : Halfword access

word : Word access

nosize : No access size

/del : Any previous setting by the command is canceled.

[Function]

The ATP3 command sets or cancels a range-of-address access break point. If in or out is specified as a address range condition, two address values, upper and lower, can be specified. In any other address range specification, only one address value can be specified.

When the command is issued, the trace buffer will be cleared, and tracing will newly begin.

- The data mask is used to specify invalid bits in the data.
- If a mask bit is 1, the corresponding data bit will not be compared. If the mask bits are ffffffff, for example, the accessed data will be utterly ignored.

[Example]

atp3 in 1020 1300 0 ffffffff access hword

Triggering occurs if a halfword at an address between 1020H and 1300H is accessed (regardless of the bit configuration of the data).

atp3 <= 1020 100 0 write word

Triggering occurs if the word 100H is written to address 1020H or lower.

env command**[Format]**

```
env rom[32|64|128|256] ram[1|2|3|4|6|8|10|12|16|20|24|28] [romless|single]
    [[!]reset][[!]wait][[!]nmi][[!]hldrq] [w0|w16|w32|w64|w128|w256]
```

[Parameters]

rom[36|64|128|256]

The size of internal ROM is specified. The sizes that can be specified include 32K, 64K, 128K, and 256K. ROM128 should be specified for the RTE-V853-IE.

ram[1|2|3|4|6|8|10|12|16|20|24|28]

The size of internal RAM is specified. The sizes that can be specified include 1K, 2K, 3K, 4K, 6K, 8K, 10K, 12K, 16K, 20K, 24K, and 28K. RAM4 should be specified for the RTE-V853-IE.

[[romless|single]

A CPU mode is specified. The CPU mode that can be specified is the ROM-less mode or single-chip mode.

[[!]reset]

Whether to mask the RESET pin is specified. Special character ! specifies not to mask the pin.

[[!]wait]

Whether to mask the WAIT pin is specified. Special character ! specifies not to mask the pin.

[[!]nmi]

Whether to mask the NMI pin is specified. Special character ! specifies not to mask the pin.

[[!]hldrq]

Whether to mask the HLDQR pin is specified. Special character ! specifies not to mask the pin.

[[!]stop]

For the RTE-V853-IE, keep this parameter at the initial value (to mask).

[w0|w16|w32|w64|w128|w256]

A wait timeout value is specified.

- w0 specifies to wait permanently.
- The other values specify that a timeout is to occur after 16 to 256 clock cycles.

[Function]

The env command is used to specify various environmental values for the emulation CPU of the RTE-V853-IE. A parameter may be omitted if it is unnecessary.

- Parameters may be written in any order.
- If parameters that are mutually exclusive are coded, the last to appear is effective.
- After the init command is issued, the initial values are as follows:

Built-in ROM capacity : 128 K

Built-in RAM capacity : 4 K

CPU mode : Single-chip mode

Pin masks : No pin is masked.

Wait time : 256 clock pulses

[Example]

```
env single !nmi
```

The single-chip mode is selected. The NMI pin is not masked.

```
env romless rom128 w16
```

The ROM-less mode is selected. The capacity of built-in ROM is set to 128 K. The wait time is specified to be 16 clock pulses.

help command

[Syntax]

help [command]

[Parameters]

command: The name of the command you want to be helped with. When the command name is omitted, the command list is displayed.

[Function]

The help command displays the help message for each specified command.

[Example]

help map

>> The information about the map command is displayed.

init command

[Syntax]

init

[Parameters]

None

[Function]

The init command initializes the RTE-V853-IE. The mapping information and environmental values are initialized. The rejection area of the memory cache is not initialized.

map_command**[Syntax]**

map [ADDR LENGTH] [guard|ram|rom|target]

[Parameters]

ADDR : The address of a location where mapping is to begin

LENGTH : The number of bytes to be mapped

[guard|ram|rom|target]: The mapping attributes are specified.

guard : Specifies a guarded area. An attempt to access the guarded area results in an error being detected.

ram : Specifies that the emulation memory be treated as RAM.

rom : Specifies that the emulation memory be treated as ROM.

target : Specifies that the memory of the target system be used.

[Function]

The map command carries out memory mapping. The V853 emulation memory can be assigned in address spaces above and below 1M.

- The size of memory assignment can be specified in 64-Kbyte units.

[Example]

map 100000 80000 ram

512 Kbytes starting at 100000h are assigned as emulation RAM.

map 0 100000 guard

1 Mbyte starting at address 0h is assigned as a guard area.

nc command**[Syntax]**

```
nc [[ADDR [LENGTH]]
```

[Parameters]

- [ADDR] : The start address of a memory cache rejection area is specified.
- [LENGTH] : The number of bytes in the memory cache rejection area is specified. The default value is 32 bytes. The minimum value that can be specified is 32 bytes.

[Function]

The RTE-V853-IE has an 8-block x 32-byte memory read cache to speed memory reference. When memory reference is repeated at the same address, an actual read operation may not be carried out. This cache operation conflicts with the actual operation of an I/O unit if it is mapped in memory. In such a case, the nc command can be used to specify a memory cache rejection area. Up to 8 blocks can be specified as a memory cache rejection area. The minimum acceptable block size is 32 bytes. An address space above 0fff000 is always a memory cache rejection area. So, it is unnecessary to specify this portion as a no-memory cache area.

[Example]

```
nc 10000 1000
```

A 1000-byte area starting at address 10000 is specified as a memory cache rejection area.

```
>nc 10000 1000
```

```
No Memory Cache Area
```

```
No.Address Length
```

```
1 010000 001000
```

```
2 fff000 001000
```

ncd command**[Syntax]**

ncd block-number

[Parameters]

block-number: The block number for a memory cache rejection area to be deleted is specified.

[Function]

The ncd command deletes a memory cache rejection area. The memory cache rejection area to be deleted is specified using a block number.

[Example]

ncd 2

Block 2 is deleted from a memory cache rejection area.

>nc

No Memory Cache Area

No.	Address	Length
-----	---------	--------

1	020000	000100
---	--------	--------

2	010000	001000
---	--------	--------

3	fff000	001000
---	--------	--------

>ncd 2

No Memory Cache Area

No.	Address	Length
-----	---------	--------

1	020000	000100
---	--------	--------

2	fff000	001000
---	--------	--------

reset command

[Syntax]

reset

[Parameters]

None

[Function]

The reset command resets the emulation CPU of the RTE-V853-IE.



rrmb command**[Syntax]**

rrmb ADDR

[Parameters]

ADDR: The base address for the real-time RAM monitor is specified.

[Function]

The rrm command specifies the base address for the real-time RAM monitor. A 1K-byte area starting at the address specified here can be referenced using rrm command, even when the CPU is running.

[Example]

rrmb 10000

A 1-Kbyte area starting at address 10000 is specified as the real-time RAM monitor area.

rrm command**[Syntax]**

rrm [ADDR[LENGTH]]

[Parameters]

ADDR : The memory reference start address in the real-time RAM monitor is specified.

LENGTH : The number of bytes (up to 256 bytes) to be read is specified.

[Function]

The rrm command accesses a location in the real-time RAM monitor memory area. The length can be up to 256 bytes.

[Example]

rrm 10000 30

30H bytes are read from the real-time RAM monitor, starting at address 10000.

sfr command**[Format]**

sfr [reg] [VAL]

[Parameters]

VAL : An SFR register value is specified in hexadecimal.

reg : An SFR register name is specified. The names that can be used for registers are listed below.

Read/write registers

P0 P1 P2 P3 P4 P5 P6 P9 P11 PM0 PM1 PM2 PM3 PM4 PM5 PM6 PM9 PM11
 PMC0 PMC1 PMC2 PMC3 MM PMC11 PCM PUO DWC BCC PSC CKC SYS BRG0 BPRM0
 CSIM0 SIO0 BRGC1 BPRM1 CSIM1 SIO1 BRGC2 BPRM2 CSIM2 SIO2 CSIM3 SIO3
 ASIM00 ASIM01 ASIM10 ASIM11 OVIC11 OVIC12 OVIC13 OVIC14
 P11IC0 P11IC1 P11IC2 P11IC3 P12IC0 P12IC1 P12IC2 P12IC3
 P13IC0 P13IC1 P13IC2 P13IC3 P14IC0 P14IC1 P14IC2 P14IC3
 CMIC4 CSIC0 CSIC1 CSIC2 CSIC3 SEIC0 SRIC0 STIC0 SEIC1 SRIC1 STIC1 ADIC
 INTM0 INTM1 INTM2 INTM3 INTM4 TOVS
 TUM11 TMC11 TOC11 CC110 CC111 CC112 CC113
 TUM12 TMC12 TOC12 CC120 CC121 CC122 CC123
 TUM13 TMC13 TOC13 CC130 CC131 CC132 CC133
 TUM14 TMC14 TOC14 CC140 CC141 CC142 CC143
 TMC4 CM4 PWCM PWPR PWM0 PWM0L PWM1 PWM1L ADM0 ADM1 DACS0 DACS1
 DAM

Write-only registers

TXS0 TXS0L TXS1 TXS1L PRCMD

Read-only registers

ASIS0 RXB0 RXB0L ASIS1 RXB1 RXB1L ISPR TM11 TM12 TM13 TM14 TM4
 ADCR0 ADCR0H ADCR1 ADCR1H ADCR2 ADCR2H ADCR3 ADCR3H
 ADCR4 ADCR4H ADCR5 ADCR5H ADCR6 ADCR6H ADCR7 ADCR7H

[Function]

The sfr command sets and displays a value in an SFR register.

[Example]

sfr TM4

A value in the TM4 register is displayed.

sfr MM 0a0

The value 0a0H is set in the MM register.

symfile and sym commands**[Format]**

symfile FILENAME : Reads a symbol file (.sym).
sym [NAME] : Displays 30 symbols.

[Parameters]

symfile : File name
sym : The first character string in symbols.

[Function]

The symfile command reads a symbol file specified as FILENAME. This command targets only global symbols. The command also displays up to 30 symbols.

[Example]

```
symfile c:¥test¥dry¥dry.sym
           The symbol file :dry.sym is read from the directory c:¥test¥dry.
sym m
           Up to 30 symbols starting with character m are displayed.
```

time command**[Format]**

time [sysclk]

[Parameters]

sysclk

[Function]

The time command displays the result of execution time measurement. Each time the CPU starts running, the execution time measurement timer is initialized and started to count. It continues to count, as long as the CPU is running. The timer has a resolution of two clock cycles.

[Remark]

The measurement value contains the overhead time (several clock cycles) needed in starting and breaking measurement.

TP, TP1, and TP2 commands**[Format]**

```
tp [ADDR] [/del]
tp1 [ADDR] [/del]
tp2 [ADDR] [/del]
```

[Parameters]

ADDR : An address value is specified in hexadecimal.
/del : Any previous setting by the command is canceled.

[Function]

The TP, TP1, and TP2 commands set and cancel execution trigger points. There are two execution trigger points. The tp command specifies an unused trigger point automatically.

- The tp1 and tp2 commands are used to specify a trigger point explicitly.

When any of these commands is issued, the trace buffer will be cleared, and tracing will newly begin.

[Example]

```
tp 1020
```

Triggering occurs when an instruction at address 1020H is executed.

TRON command**[Format]**

tron [DELAY] [add|cycle]

tron [x1|x2|x4|x8|x16|x32|x64|x128|x256|x512|x1k|x4k|x16k|x64k|x256k]

[Parameters]

DELAY=0..07fff Delay counter

The number of instruction cycles (delay counter) during which tracing should continue since the occurrence of triggering is specified in hexadecimal. The trace buffer can hold data for up to 32K cycles.

x1..x1m Trace timer counter frequency division ratio

The frequency division ratio for the time tag counter clock is specified. The setting x16 means that the timer unit is multiplied by 16.

add The addition mode is specified.

In this mode, a value from the previous cycle is accumulated.

cycle The cycle mode is specified.

The trace timer tag counter value is displayed for an individual cycle.

[Function]

The TRON command clears the trace buffer and begins recording trace data.

[Caution]

1. Even when the addition mode is specified for the timer counter, the time tag will be cleared at restart if a break occurs.

[Example]

tron 100 x16 cycle

Tracing is terminated after data for 100h (256) cycles has been recorded since the occurrence of triggering. The timer unit is multiplied by 16. Execution results are written to the trace buffer in every cycle.

TROFF command

[Format]

troff

[Parameters]

None

[Function]

The TROFF command forcibly terminates tracing.

TRACE command

[Format]

trace [POS] [asm]

[Parameters]

POS= ±0..07fff Read start position (with the trigger point or end point as 0)
 The number of cycles counted from the beginning of the trace buffer is specified in hexadecimal.

asm Display type (assembler)...displayed in a disassembly form

[Function]

The TRACE command displays the contents of the trace buffer.

- Tracing is terminated when this command is issued.
- To restart tracing, it is necessary to issue the tron command.

[Display] Assembly mode

	Frame	neis	Time	Ext	Address	Code	Operand
_start:							
-0003	--i-	0003	0000	00000800	401e0000	movehi	0000h, zero, sp
-0002	--i-	0003	0000	00000804	231efcef	movea	-1004h, sp, sp
-0001	--i-	0001	0000	00000808	40360000	movehi	0000h, zero, r6
+0000	--i-	0001	0000	0000080c	26365c11	movea	+115ch, r6, r6
+0001	--i-	0001	0000	00000810	6600	jmp	[r6]
main:							
+0002	--i-	0003	0000	0000115c	5c1a	add	-04h, sp
+0003	--i-	0001	0000	0000115e	63ff0100	st.w	lp, +00h [sp]
					00000246	Write	00000246h-> [00ffeff8h]
main+0006h:							
+0004	--i-	0001	0000	00001162	bfff64f8	jarl	RegChkInit (000009c6h)
RegChkInit:							
+0005	--i-	0003	0000	000009c6	501a	add	+10h, sp
+0006	--i-	0001	0000	000009c8	63ff0d00	st.w	lp, +0ch [sp]
					00001166	Write	00001166h-> [00ffeff4h]
+0007	--i-	0001	0000	000009cc	63b70900	st.w	r22, +08h [sp]
					00000000	Write	00000000h-> [00ffeff0h]
+0008	--i-	0001	0000	000009d0	63af0500	st.w	r21, +04h [sp]
					00000908	Write	00000908h-> [00ffefech]

Frame : A trigger position is specified in hexadecimal with the first trigger cycle as 0.

- neis : The PSW flag is displayed.
n : NMI flag
e : External interrupt flag
i : Exception flag
s : Saturation flag
- Time : The trace timer tag counter is displayed in hexadecimal.
- Ext : External data is displayed in bit units (in sequence of EXT0, 1, 2, 3 from the right).
- Address : An instruction execution address is displayed in hexadecimal.
- Code : For execution tracing, an instruction code is displayed in hexadecimal. For data tracing, data is displayed in hexadecimal.
- Operand : An instruction is displayed in a disassembly form.
Data is displayed in the following format:
Read [address] <- data
Write data -> [address]
The number of digits in the data means the data size.

<<Caution>>

The first two frames of the time display contain error. If add (addition mode) is specified in the tron command, the first frame is not subjected to addition.

ver command

[Syntax]

ver

[Parameters]

None

[Function]

The ver command indicates the version of the RTE-V853-IE.



APPENDIX B. RTE-V853-IE USER INTERFACE CIRCUITS



